

JSCS40 Salt System Low Salt Troubleshooting Guide



Situation	Cause	Corrective Action
Power light is flashing OR service light is on while operating on low output percentage.	Low salt level, dirty cell, damaged cell blade coatings.	Set the output to “Boost” and then hold down the upward arrow button until the polarity lights begin to flash back and forth. Check to see if power light has stopped flashing or the service light has turned off.
Unable to increase chlorine production	Cold water, low salt level, or cell is over-calcified	Check cell and clean, check salt level, check water temperature.
Power light is flashing and service light is on.	*Sensor tab (top of cell) issues.	Clean off any calcium on sensor tab. Make sure there is not an air bubble at point of sensor tab in cell housing

* The sensor tab is not replaceable. It reads salt levels, water temperature, and flow of water in cell housing. Use caution when cleaning this and the cell and not to cause any damage.